

Follow instructions before operating.



continuous innovations

# Next Series 8 and Quantum CIJ Printer Commissioning guide

Part Number: 49-0005-01 (Rev. E) Software version 01.06.00.10+

**Updated: March 2023** 

**PERSONAL INJURY:** ALWAYS WEAR RUBBER GLOVES AND SAFETY GLASSES WHEN HANDLING INKS AND SOLVENTS.

**PERSONAL INJURY:** ALWAYS WEAR RUBBER GLOVES AND SAFETY GLASSES DURING FLUIDIC MAINTENANCE.



PERSONAL INJURY: INKS AND SOLVENTS ARE POISONOUS, DO NOT INGEST.

**PERSONAL INJURY:** DO NOT USE SOLVENT TO WASH INK FROM SKIN. IF EXPOSED, GENTLY RINSE AREA WITH SOAPY WATER. IF IRRITATION PERSISTS, SEEK MEDICAL ATTENTION.

**PERSONAL INJURY:** BE AWARE OF DANGERS ASSOCIATED WITH FLUIDS. DO NOT USE A FLUID UNTIL YOU ARE FAMILIAR WITH THE SDS AND THE INGREDIENTS.

**PERSONAL INJURY:** FOLLOW ALL SAFETY GUIDELINES OUTLINED IN THE SDS OF THE FLUIDS BEING USED.

**EQUIPMENT DAMAGE:** DO NOT ADD FLUIDS UNLESS INSTRUCTED BY INDICATORS.

**EQUIPMENT DAMAGE:** THE PRINTHEAD MUST BE DRY BEFORE STARTING PRINTER.



**EQUIPMENT DAMAGE:** THE PRINTHEAD SHOULD NEVER BE COMPLETELY SUBMERGED IN SOLVENT.

**EQUIPMENT DAMAGE:** DO NOT ATTEMPT TO USE MULTIMETER TO TAKE MEASUREMENTS ON ANY COMPONENT WHILE THE MACHINE IS POWERED ON.

**EQUIPMENT DAMAGE:** DO USE MULTIMETER TO ATTEMPT TO MEASURE THE CHARGE VOLTAGE AT THE PRINTHEAD. THIS WILL PERMANENTLY DAMAGE THE MAIN BOARD



**FIRE HAZARD:** INKS AND SOLVENTS ARE HIGHLY FLAMMABLE. NO SMOKING OR OPEN FLAMES NEAR PRINTER OR FLUID STORAGE.



**ELECTRICAL SHOCK:** DISCONNECT MAIN POWER CABLE PRIOR TO SERVICING MACHINE.

**ELECTRICAL SHOCK:** NEVER RUN MACHINE WHILE ELECTRONICS COMPARTMENT DOOR IS OPEN.

# **CodeProtect** ™BestCode Warranty and Support

BestCode products are delivered with a 2 Year Manufacturer's Limited Warranty. Call or email your local distributor for detailed warranty information.





**EQUIPMENT DAMAGE:** Follow these instructions before powering on the machine. Failure to connect pump tubes may lead to permanent pump damage.

# Pre-Power Up Guide

- 1. Locate the ¼" pump tubes with Red and Black coding.
- 2. Remove the Red and Black end from the pump.



The red tube is on the pressure side of the pump, and flows into the main ink filter. Verify the tube connects directly to the main BestCode Ink Filter.

# Procedure Time: 2 minutes






- 3. Remove the Black cap from the tube.
- 4. Wet the pump fitting o'ring with cleaner and firmly press the black tube into the <u>rear</u> fitting on the pump.




Pull back on the tube to ensure that it is completed seated and sealed into the pump fitting. Failure to fulling insert to tube will cause ink leakage.





The black tube is on the vacuum side of the pump, ensure that it is connected to the lnk Pickup tube in the lnk Tank.






6. Remove the Nozzle Shipping Gasket.
The gasket is highly elastic and should be stretched outwards and then lifted up from between the nozzle and charge electrode.



#### Commissioning


The commissioning process is a 90–120-minute step by step guide for installing and preparing the Next Series 8 or Quantum CIJ for production operation.

Make sure the Controller is properly mounted.



- 2. After the Success pop-up, remove the cap and press the bottle firmly into the Ink Smartfill Cup.
- 3. Press OK after the bottle has completely drained.





#### Series 8 Printer

4. Place 1 un-opened bottle of Makeup in the Makeup Smartfill Cup then press the Makeup Level button on the Home Screen.(Leave the Makeup Cap on!)

## **Quantum Printer**

4. Place 1 un-opened bottle of Make-up In front of the Smartfill scanner then press the Make-up level button on the Home screen.







- 1. After the Success pop-up, remove the cap and press the bottle firmly into the Makeup Smart Fill Cup.
- 2. Press OK after the bottle has completely drained.





## First time jet Start

- 1. Secure the printhead into the Printhead Clean Station (40-002-01)
- 2. Disable the High Voltage, and Phase







- 3. Press the Start Button on the Service Screen
- 4. Clear any errors that appear and repeat from Step 3 until the jet starts without errors.



5. Stop the Jet, then perform the backflush nozzle routine up to 6 times. 6. Dry the printhead, then start the Jet normally with Errors, High Voltage and Phase enabled. HV Deflect Enabled Verify the Modulation Process Time: 30-75 minutes (depending on ink viscosity) 1. Run until the Viscosity is within range Viscometer: Wait, 49 of the Target Viscosity. (2.3-3.3cP or Target: 4.5 cP, Actual: 4.5 cP, 81.2 s 4.0-5.0cP depending on ink type) Printhead: 24 °C, Electric: 27 °C Modulation: 2. Decrease modulation to 30V below 140 Volts - B the set point and test the print 94/18/18 3. Increase the modulation to 30V Modulation: above the set point and test the print 200 Volts - B a. If the print is not acceptable, 15:44:99 perform a modulation 04/18/18 calibration. Modulation: 170 Volts - A 4. Return the Modulation to the set point and inspect the drop breakup.

# BestCode Information

3034 SE Loop 820 Fort Worth TX 76140 USA www.bestcode.co Phone: (+1) 817-349-8555 Fax: 817-349-8480 For product questions email: info@bestcode.co

BestCode product and fluids are available through distribution around the globe. Contact your local BestCode distributor for ordering information.



